



PART NUMBER

PFF60-822

DESCRIPTION

RENAULT CLIO 1 197 SPORT ENGINE MOUNT TOP

INSTALLATION GUIDE

Product description:

This polyurethane bush is designed to fit into the original aluminium casting of the upper engine torque mount.

Contents (parts per pack):

- 1 x Polyurethane bush
- 1 x Stainless steel sleeve
- 1 x Grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove original rubber bush from the arm, clean any dirt and corrosion from the bore in arm.
2. Push the bush into the arm until it sits flush with the arm on both sides.
3. Apply some of the supplied grease to the bore of the bush and insert the sleeve into the arm. The smallest diameter of the sleeve fits into the smaller end of the bush.
4. Refit the arm to the car using the original bolt and tension all hardware to manufactures recommended torque settings.

