

POWERFLEX®

PART NUMBER

PFR5-4626

DESCRIPTION

REAR DIFF REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 1 x polyurethane bush
- 1 x stainless steel sleeve
- 1 x washer
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove rear diff rear bush from the subframe. Clean any rust and dirt from around the surrounding area of the subframe.
2. Push the new bush into the subframe from the centre of the car outwards so the larger diameter end of the bush fits against the diff.
3. Apply some of the supplied grease to the bore of the bush, push the sleeve into the bush.
4. Whilst refitting the diff, fit the new washer between the bush and diff. Re use the original bolts and washers.

Centre of car



Outside of car



Diff fits against washer